

Use of Zebra DS2208 Reader

United Nations
Educational, Scientific and
Cultural Organization

Regional Centre for
Library Information Systems and
Current Research Information Systems
Regionalni center za knjižnične
informacijske sisteme in informacijske
sisteme o raziskovalni dejavnosti

IZUM

© IZUM, 2024.

IZUM, COBISS, COMARC, COBIB, COLIB, CONOR, SICRIS, E-CRIS, COBISS3, mCOBISS, COBISS+, dCOBISS, COBISS4, SGC, COBISS Lib, COBISS Cat, COBISS Ela are registered trademarks owned by IZUM.

CONTENTS

1 Use of Zebra DS2208 reader 1

2 Setting up the reader 1

2.1 Setting up the volume 2

3 Testing the setup parameters and reading barcodes 3

1 Use of Zebra DS2208 reader

Reader with USB-interface:

1. Attach the enclosed cable with the 10-pin mini connector to the available slot on the reader.
2. Plug the other end of the cable to the available slot on the PC (USB-interface).
3. Wait for Windows to automatically detect the new hardware and install the drivers (no additional installation CD required).



2 Setting up the reader

Set up the reader by reading the barcodes from top to bottom. Each step is explained to the left of the barcode.

1	Reader reset ***Factory setting →***	
2	Keyboard setup ***Slovene keyboard →***	
3	Setup of transition to new row ***Enter Key →***	

2.1 Setting up the volume

Set up the volume by selecting one of the following options:

1a	**Volume for successful read**: ***low*** →	
1b	**Volume for successful read**: ***medium*** →	
1c	**Volume for successful read**: ***high*** →	

© IZUM, 4. 10. 2024, VOS-NA-EN-529, V1.0

3 Testing the setup parameters and reading barcodes

Check if the parameter setup was successful by reading the test barcodes below:

COBISS	Additional barcodes
CODE 93 ABC-1234-/+	Interleaved 2 of 5 0 1 2 3 4 5 6 7 8 4
Code 128 t e s t	Interleaved 2 of 5 0 1 2 3 4 5 6 7 8 **Without check digit (4)!**
EAN-13 1 234567 000992	 123ABC Code 39
	 057654850 Codabar